



EZ6001 Total Dissolved Arsenic Analyser As(III+V)

Продукт №: EZ6001.XXXXXXXXXX

BGN Цена: Свържете се с нас

Trace metal analysis of Total Dissolved Arsenic As(III+V) in water by online voltammetry

About the 6000 Series

The EZ6000 Series of Online Trace Metal Analysers are based on the technology of stripping voltammetry, a sensitive analytical technique that can be automated for the determination of trace levels of metals in water. For many metals the EZ6000 Series boasts limits of quantification in the low ppb range, comparing the technique favorably with AAS or ICP analysis.

Single, multiple and total parameter configurations

Several product sublines with a wealth of combinations are available for determination of trace metals, including the standard single parameter and multi-parameter configurations without digestion. Measurement of complexed or adsorbed metals is possible by means of the configurations with built-in digester. Combinations of metals depend on the choice of working electrode and the priority metals for your application.

Advanced features

The EZ6000 Series build upon tried and tested voltammetry technology used in many clean water applications, in an industrial mainframe with the following prime features:

- Excellent selectivity and sensitivity
- Built-in sample digestion unit (hot acid or UV)
- Smart automatic features
- Standard 4 - 20 mA signal output with alarm processing
- Communication ports supporting connectivity to Modbus
- Higher measuring ranges: internal sample dilution
- Multiple stream analysis

There are many additional options available. Please contact Hach for more details.

Спецификации

Cooling water: Not required

Demineralised water:	For rinsing
Digital outputs:	Optional: Modbus (TCP/IP, RS485)
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm ²
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Precision:	Better than 5% full scale range for standard test solutions
Reagent Requirements:	Keep between 10 - 30 °C
Validation:	Automatic; frequency freely programmable
Аварийен сигнал:	1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Автоматично почистване:	Да
Аналогови изходи:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Бр. потоци проби:	1, 2, or 4
Гаранция:	24 месеца
Граница на откриваемост:	≤ 1 µg/L
Дренаж:	Atmospheric pressure, vented, min. Ø 32 mm
Захранване:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Измерване метод:	Stripping voltammetry using gold electrode
Измерване, диапазон:	1 - 20 µg/L As
Какво има в кутията:	EZ6001 Arsenic Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x Reference Electrode (Ag/AgCl), 1 x Working Electrode - Gold, 1 Counter Electrode, 1 x empty 5L Reagent Container with Fittings (Buffer Solution) and 1 x empty 10L Reagent Container with Fittings (H2SO4) and 2 x empty 1L Reagent Containers with Fittings (Reference Blank & Reference As Solution)
Калибриране:	Automatic, 2-point; frequency freely programmable
Клас на защита:	Analyser cabinet: IP44 / Panel PC: IP65
Кювети за проба:	10 minutes
Материал:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Модел:	EZ6001
Околна температура:	10 - 30 °C ±4 °C deviation at 5 - 95% relative humidity (non-condensing)
Параметър:	Arsenic, total dissolved As(III+V)
Проба, дебит:	100 - 300 mL/min
Проба, качество:	Maximum particle size 100 µm, < 0.1 g/L; Turbidity < 50 NTU
Проба: налягане:	By external overflow vessel
Размери (В x Ш x Д):	690 mm x 465 mm x 330 mm
Сертификати:	CE compliant / ETL certified
Смущения:	Iodide, organic matter, copper Cu(II) > 30 µg/L, iron Fe(III) >20 mg/L, various metals in mg/L levels may interfere. Fats, oil, proteins, surfactants and tar.
Тегло:	25 kg
Температура на проба:	10 - 30 °C

Какво има в кутията

EZ6001 Arsenic Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x Reference Electrode (Ag/AgCl), 1 x Working Electrode - Gold, 1 Counter Electrode, 1 x empty 5L Reagent Container with Fittings (Buffer Solution) and 1 x empty 10L Reagent Container with Fittings (H₂SO₄) and 2 x empty 1L Reagent Containers with Fittings (Reference Blank & Reference As Solution)